


TAP Pad Sensitivity Adjustment Quickstart



Sensitivity can be adjusted independently for each pedal using the two blue knobs. Twist counter-clockwise to increase sensitivity (softer taps); twist clockwise to decrease sensitivity (harder hits).

It is best to keep the sensitivity of both pads set similarly. If set dissimilar, striking one pad could inadvertently trigger the other pad.

Questions? Comments? Call us at 1-888-247-1223, or email support@airturn.com, subject "TAP"