



(1) EXTERIOR and CH FADER SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
A	1 CH1FD Assy	DWX3689	26	Holder	DNK6425
	2 CH2FD Assy	DWX3690	27	Slider	DNK6426
	3 Connector Assy	PF03PP2B07	28	Brake	DNK6427
	4 Connector Assy	PF03PP-B17	29	Stopper	DNK6440
	5 Connector Assy	PF04PP-B12	30	Knob	See Contrast table (2)
	6 Plug/Pin	DKM1024	31	Slider Knob 2	See Contrast table (2)
	7 Rotary SW Knob (MA)	DAA1198	32	Panel	See Contrast table (2)
	8 Rotary SW Knob S (C)	DAA1204	33	Guide Bar	VLL1514
	9 Knob/RSW	DAA1305	34	Fader Bumper A	GNK1010
	10 Knob	DAA1344	35	Fader Bumper B	DEC3596
B	11 Knob	DAA1345	36	Fader Bumper C	DEC3605
	12 Knob/CL	See Contrast table (2)	37	
	13 Knob	DAA1346	38	Screw	BBZ30P060FTC
	14 Knob	DAC3088	39	Screw	BPZ20P050FTC
	15 Plate	DAH3033	40	Screw	BPZ30P080FNI
	16 Window	DAH3034	41	Screw	BSZ30P060FTB
	17 Damper	DEB2032	42	Screw	CPZ26P080FTC
	18 Fader Packing (B)	DEC2572	43	Screw	IBZ30P080FTB
NSP	19 Cushion	DEC3356	44	Screw	See Contrast table (2)
C	20 Felt	DEC3603			
	21				
	22 Cushion	DEC3639			
	23 Packing	DEC3642			
	24 Stay	DNF1942			
	25 Lever	DNH3211			

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>DJM-S9 /LSYXJ</u>	<u>DJM-S9 /UXJCB</u>	<u>DJM-S9-N /LSYXJ</u>	<u>DJM-S9-N /UXJCB</u>
	12	Knob/CL	DAA1320	DAA1320	Not used	Not used
	12	Knob	Not used	Not used	DAA1350	DAA1350
	30	Knob	DAC3089	DAC3089	DAC3100	DAC3100
	31	Slider Knob 2	DAC2685	DAC2685	Not used	Not used
	31	Knob	Not used	Not used	DAC3164	DAC3164
	32	Panel	DNB1241	DNB1241	DEA1038	DEA1038
E	44	Screw	DBA1446	DBA1446	DBA1447	DBA1447