



* This acetate tape is for protecting cables.
If it is peeled away, be sure to adhere new acetate tape.



(1) CHASSIS SECTION (1/2) SECTION PARTS LIST

	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
A	1	HPJK Assy	DWX3686		21 Shield Case	DNF1946
	2	INPUT Assy	DWX3683	⚠	22 Holder	DNK6429
	3	ATT Assy	DWX3682		23 Guard	DNK6441
	4	FRVR Assy	DWX3687	⚠	24 Panel	See Contrast table (2)
	5	MCSW Assy	DWX3688		25 Guide Bar	VLL1514
B	6	FFC	DDD1701		26	
	7	FFC	DDD1702		27	
	8	Connector Assy	PF06PP-D05		28 Nut M12	DBN1018
	9	Shielded Conn-Cable	DDA1059		29 Nut	NK90FTC
	10	Knob	DAA1348		30 Screw	AMZ26P040FTC
	11	Cap/MIC	DAC2773		31 Screw	BBZ30P060FTB
	12	Spring	DBH1810		32 Screw	BBZ30P060FTC
	13	Damper/SI	DEB2008		33 Screw	BPZ30P080FNI
	14	Slide SW Packing (B)	DEC2590		34 Screw	BPZ30P080FTB
	⚠	15 Insulating Sheet	DEC3629		35 Screw	BSZ30P060FTB
C	16	Cushion	DEC3640		36 Screw	CPZ26P080FTC
	17	SW Packing	DED1177			
	18	Shield Case	DNF1943			
	19	Stay	DNF1944			
	20	Stay	DNF1945			

(2) CONTRAST TABLE

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-S9 /LSYXJ	DJM-S9 /UXJCB	DJM-S9-N /LSYXJ	DJM-S9-N /UXJCB
⚠	24	Panel	DXA2291	DXA2291	DXA2298	DXA2298