


# 9.7 PANEL SECTION (2/2)

• Bottom view



5 6 7 8

**PANEL SECTION (2/2) SECTION PARTS LIST**

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Matrix OEL	MXS4057	16	Button	DXA2289
2	Button	DAC3082	17	Button	See Contrast table (2)
3	Button	DAC3084	18	Button	See Contrast table (2)
4	Button	DAC3090	19	Button	See Contrast table (2)
5	Button	DAC3093	20	Button	See Contrast table (2)
6	Button	DAC3094	21	Button	See Contrast table (2)
7	Button	DAC3095	22	Panel	See Contrast table (2)
8	Button	DAC3096	23	Panel	See Contrast table (2)
9	Button	DEB2015			
10	Sheet	DEC3604			
11	Spacer	DEC3641			
12	Shield Plate	DNF1969			
⚠ 13	Panel	DNK6438			
14	Holder	DNK6439			
15	Holder	DNK6443			

**(2) CONTRAST TABLE**

DJM-S9/LSYXJ, DJM-S9/UXJCB, DJM-S9-N/LSYXJ and DJM-S9-N/UXJCB are constructed the same except for the following:

<u>Mark</u>	<u>No.</u>	<u>Symbol and Description</u>	<u>DJM-S9 /LSYXJ</u>	<u>DJM-S9 /UXJCB</u>	<u>DJM-S9-N /LSYXJ</u>	<u>DJM-S9-N /UXJCB</u>
	17	Button	DAC3085	DAC3085	DAC3101	DAC3101
	18	Button	DXA2288	DXA2288	DXA2290	DXA2290
	19	Button	DAC3087	DAC3087	DAC3102	DAC3102
	20	Button	DAC3091	DAC3091	DAC3103	DAC3103
	21	Button	DAC3092	DAC3092	DAC3104	DAC3104
	22	Panel	DNK6436	DNK6436	DNK6457	DNK6457
	23	Panel	DNK6437	DNK6437	DNK6459*	DNK6459*

\*The serial number is not printed on this part for service.

DJM-S9

5 6 7 8

67