


9. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The \triangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ∇ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠	1 Power Cord	See Contrast table (2)	13	Sub Manual	See Contrast table (2)
	2 USB Cable	DDE1150	14	Sub Manual	See Contrast table (2)
	3 Packing Pad	DHA1999	15	Sub Manual	See Contrast table (2)
	4 Packing Pad	DHA2000	16	•••••	
	5 Packing Pad	DHA2003	NSP 17	Warranty	See Contrast table (2)
	6 Packing Case	See Contrast table (2)	NSP 18	1..License Key Card Assy	DEA1046
	7 Mirror Mat	DHL1201	NSP 19	2..Leaflet	DRM1410
NSP	8 Polyethylene Bag	AHG7117	NSP 20	2..rekordbox dj license key card	DXA2304
	9 Operating Instructions (Quick nStart Guide)	See Contrast table (2)	21	Label	See Contrast table (2)
	10 Operating Instructions (Quick nStart Guide)	See Contrast table (2)	22	Label	See Contrast table (2)
	11 Operating Instructions (Quick nStart Guide)	See Contrast table (2)	NSP 23	Label	See Contrast table (2)
	12 Operating Instructions (Quick nStart Guide)	See Contrast table (2)			

(2) CONTRAST TABLE

XDJ-XZ/AXJ, LWSYXJ and UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	XDJ-XZ/AXJ	XDJ-XZ/LWSYXJ	XDJ-XZ/UXJCB
⚠	1	Power Cord	DDG1114	ADG1244	DDG1108
	6	Packing Case	DHG3732	DHG3731	DHG3731
	9	Operating Instructions (Quick nStart Guide)(En)	Not used	Not used	DRH1539
	10	Operating Instructions (Quick nStart Guide)(En, Fr, De, It)	Not used	DRH1540	Not used
	11	Operating Instructions (Quick nStart Guide)(NI, Es, Pt, Ru)	Not used	DRH1541	Not used
	12	Operating Instructions (Quick nStart Guide)(Zhcn)	DRH1542	Not used	Not used
	13	Sub Manual	DRH1594	Not used	Not used
	14	Sub Manual	Not used	DRH1592	DRH1592
	15	Sub Manual	Not used	DRH1593	DRH1593
NSP	17	Warranty	Not used	DRY1270	Not used
	21	Label	Not used	Not used	DRW2831
	22	Label	Not used	Not used	DRW2839
NSP	23	Label	Not used	DRW2838	DRW2838