

9.2 BOTTOM SECTION

1

2

3

4

A


B

C

D

E

F



1

2

3

4

(1) BOTTOM SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	USBA Assy	DWX4294	16	•••••	
2	MCTR Assy	DWX4302	17	Holder	VEC1355
3	STL4 Assy	DWX4322	18	Knob	DAA1442
4	Shielded Conn-Cable	DDA1094	19	Binder	ZCA-SKB90BK
5	FFC	DDD1952	20	Stay	DNH3429
6	FFC	DDD1953	21	Rear Panel	See Contrast table (2)
7	Cushion/FFC	DEC3531	22	•••••	
8	Gasket/JOG	DEC3562	23	Screw	BBZ30P060FTB
9	Cushion	DEC3592	24	Screw	BBZ30P060FTC
10	Cushion	DEC3887	25	Screw	BPZ30P080FNI
11	Barrier	DEC3888	26	Screw	BPZ30P100FTB
12	Stay	DNH3311	27	DM Screw (FTC)	DBA1260
13	Base	DNK6708			
⚠ 14	Chassis	DNK6862			
15	Insulator Assy	DXB2131			

(2) CONTRAST TABLE

XDJ-XZ/AXJ, LWSYXJ and UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	XDJ-XZ/AXJ	XDJ-XZ/LWSYXJ	XDJ-XZ/UXJCB
	21	Rear Panel	DAH3271	DAH3268	DAH3269