



9.3 CHASSIS SECTION

A
B
C
D
E
F



CHASSIS SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	MAIN Assy	DWX4287	
2	AUDIO Assy	DWX4298	A
3	MCIN Assy	DWX4300	
4	STL1 Assy	DWX4319	
5	STL2 Assy	DWX4320	
6	STL3 Assy	DWX4321	
⚠	7 SW POWER SUPPLY	DWR1548	
⚠	8 AC Inlet	DKP3994	
	9 Crimp Connector	DKP3993	
	10 FFC	DDD1950	
	11 Connector Assy	PF06PP-D37	B
	12 Heat Cond Sheet	DEB2020	
	13 Heat Cond Sheet	DEB2073	
	14 Earth Terminal	DKE1015	
	15 Stay	DNH3430	
	16 •••••		
	17 Bracket	DNH3431	
	18 Shield Case	DNH3432	
	19 Shield Case	DNH3433	
	20 Shield Case	DNH3434	C
	21 Shield Case	DNH3435	
	22 Shield Case	DNH3436	
	23 Support	DNK6869	
NSP	24 PCB Holder	PNW1706	
	25 Holder	VEC1355	
	26 •••••		
	27 •••••		
	28 Nut (M12)	NKX2FNI	
	29 Washer	WA32F100Q050	D
	30 Spring Lock Washer	WS40FNI	
	31 Screw	BBZ30P060FTC	
	32 Screw	IBZ30P080FTB	
	33 Screw	PMH40P080FTC	
	34 Screw	PPZ30P080FTB	
	35 Screw (M3 * 5)	DBA1340	