

CONTROL PANEL SECTION (1/3) PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	UCOM Assy	DWX4296	46	CHF2 Assy	DWX4304
2	EFSW Assy	DWX4297	47	CHF3 Assy	DWX4305
3	MIXER Assy	DWX4299	48	CHF4 Assy	DWX4306
4	PWSW Assy	DWX4312	49	Connector Assy (CH1 to CH3)	PF03PP-B05
5	HPJK Assy	DWX4301	50	Connector Assy (CH4)	PF03PP-B07
6	FFC	DDD1935	51	Guide Shaft VK1	DLA1978
7	FFC	DDD1943	52	Lever Plate	DNH2954
8	FFC	DDD1944	53	VR Stay	DNH2955
9	FFC	DDD1946	54	Slider Base	DNK5851
10	Knob	DAA1406	55	Shaft Holder	DNK5852
11	Cord Clamper (Steel)	RNH-184	56	Screw	BPZ20P060FTC
12	Rotary SW Knob (C)	DAA1180	57	Screw	CPZ26P080FTC
13	Select Knob	DAA1205	58	Screw	PMH20P040FTC
14	Knob/LBK	DAA1284			
15	Knob/RSW	DAA1305			
16	Knob/FRE	DAA1309			
17	Knob	DAA1408			
18	Knob	DAA1409			
19	Knob	DAA1432			
20	Knob	DAA1434			
21	Knob	DAA1435			
22	Power Knob	DAC2306			
23	Slide SW Cap (W)	DAC2401			
24	Knob	DAC3539			
25	Slider Knob 2	DAC2685			
26	Cap	DAC3136			
27	Knob	DAC3238			
28	Sheet	DEC3843			
29	Barrier	DEC3847			
30	Barrier	DEC3848			
31	Barrier	DEC3849			
32	Stay/HP	DNH3182			
33	Stay	DNH3426			
34	Stay	DNH3427			
35	Slider Knob Stopper	DNK5888			
36	Knob/SLD	DNK5981			
37	Stopper	DNK6440			
38	Nut M12	DBN1018			
39	Screw	BBZ30P060FTC			
40	Screw	BPZ30P080FNI			
41	Screw	BPZ30P100FTB			
42	Screw	BSZ20P040FTB			
43	•••••				
44	•••••				
45	CHF1 Assy	DWX4303			