



# 9.6 CONTROL PANEL SECTION (3/3)

1 2 3 4

A • Bottom view




C • Top view



1 2 3 4

•The position of the divided parts / 分割部品の取り付け位置



CONTROL PANEL SECTION (3/3) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
	1..Control Panel Service Assy	DEA1094	21	Button/EF	DAC3040
△NSP 2	2..Control Panel	DNK6863	22	Button/LOP	DAC3074
3	2..Slide Sheet 1C	DAH2404	23	Button	DAC3285
NSP 4	2..Plate	DAH3261	24	Button	DAC3287
NSP 5	2..Plate	DAH3262	25	Button	DAC3363
NSP 6	2..Plate	DAH3263	26	Button	DAC3413
NSP 7	2..Plate	DAH3265	27	Button	DAC3478
NSP 8	2..Plate	DAH3266	28	Button	DAC3479
NSP 9	2..Plate	DAH3267	29	Button	DAC3480
10	2..Packing	DEC3642	30	Button	DAC3481
11	2..Gasket	DEC3719	31	Button	DAC3482
12	2..Sheet	DEC3795	32	Button	DAC3483
NSP 13	2..DS Tape	DEH1108	33	Button	DAC3502
NSP 14	2..DS Tape	DEH1109	34	Frame	DNH3423
15	Button/TMP	DAC2845	35	Ring Rens (PLAY)	DNK5315
16	Button/CAL	DAC3020	36	Lens	DNK5862
17	Button/DLT	DAC3021	37	Button Unit	DXB2198
18	Button/RVL	DAC3023			
19	Button/MT	DAC3029			
20	Button/REL	DAC3030			