


XERO

POLY LOOPER




Thank you for picking up the Xero! Scan the QR code on the back to see how you can fully explore the creative possibilities of multiple loop channels, and how they can interact! We also know you just want to play, so to get started:

- Press the Left stomp to record.
- Press again to stop recording & automatically begin playing back your loop.
- Hold left stomp to undo.
- Press both stomps simultaneously to switch to enable recording on channel 2. Press again to enable both channels. Press once more to cycle back to channel 1.
- Press the Right stomp to stop playback.
- Hold the Right stomp to activate speed effects.

The use of an isolated power supply is recommended for powering all Walrus Audio Pedals. Daisy chain power supplies are not recommended.

9 volt DC, Center Neg.
300mA min*



XERO

POLY LOOPER

This product comes with a limited lifetime warranty. Scan the code below to register your pedal, view the full manual, leave a review, and more.

We also staff a real live human to answer emails for repairs, questions, and general life advice. help@walrusaudio.com

